

 \triangleright

۲

5

Lower Anchorages



 \bigcirc

11

۲

company regarding its policy on replacement of child restraints. Using any child restraint when uncertain if it is damaged puts your child at risk for injury or death.

- Care And Cleaning: Vest: Surface wash with mild solution of soap and water. Air Dry, Machine wash in laundry bag, on gentle
- cycle with mild detergent then air dry. Locking Device: Rinse with warm water. DO NOT use household detergents.
- Top Tether: Surface wash with mild solution of soap and water. Air Dry. Go to ridesafer.net/FAQ for detail.
- Crotch Belt: Surface wash with mild solution of soap and water. Air Dry. Do not machine wash.